

# Test Equipment for Lab and Production Products for




## Paint/ Coatings



Plastics/ Rubber



**Pipes** 



Special Solutions/ Service Strength Coesfeld GmbH & Co. KG Tronjestr. 8 44319 Dortmund

Tel. +49 (0) 231 91 29 80 0 Fax. +49 (0) 231 17 98 85

mail@coesfeld.com www.coesfeld.com









## Surface, Paint, Coatings



The test equipment of this field empraces physical, electrical and thermical test of powder coating, hartz, paint, lacquer and plastic coating. This includes mechanical tests as abraision and gauge, electrical test as cathodic disponding, resistance, and coating thickness, thermical tests as gel time, film forming temperature, softening, melting point, evaporation and corrosion.



**MFFT Gradient Plate** 

page 15



**Gel Time** 

page 15



Plastic granulate pouring funnel

page 15

Coesfeld GmbH & Co. KG Tronjestraße 8 \* 44319 Dortmund Telefon: +49 231 91 29 80 0 Telefax: +49 231 17 98 85





## **Apparent Density Tester**

page 15



## Floatation and Apparent Density

page 15



## **Gauge Tester**

page 15



#### **Wear Resistance**

page 15



## **Cathodic Disbonding**

page 15



## **Coating resistivity**

#### Tera ohm meter

for resistance measurement

- 3 device configurations with different resistance ranges
- programmable data storage with read-out by PC or device
- wide range of electrodes available

2 of 15

Telefon: +49 231 91 29 80 0 Telefax: +49 231 17 98 85





## **Holiday testing**

#### Holiday detector

for non-destructive holiday detection of coatings via high voltage impulse technology test

- sensitive coatings like FBE, enamel, epoxy, halar etc.
- intelligent signal analysis allows testing of completely coated parts
- menu-driven sensitivity guarantees exact results

#### **Others**

**COESFELD** 

Telefon: +49 231 91 29 80 0

Telefax: +49 231 17 98 85

page 15

E-Mail: mail@coesfeld.com



## 50-113 / 50-130 MFFT 10 and MFFT 20

#### **Standards**

ISO 2115 - ASTM D 2354



#### **Application**

Temperature gradient plate for measuring the Minimum Film Forming Temperature, MFFT of polymer dispersion.

#### **Features**

For determination of the MFFT a sample is applied on the tempered measuring plate by the help of a film caster. A visual inspection of the dry film is then made to determine the position along the length of the film where it changes from the coalesced to the non-coalesced state. A non-coalesced film shows whitening and /or cracking. The lowest temperature at which the film is coalesced is reported as the MFFT.

The temperature gradient plate consists of a high precision chromium measuring plate, with equispaced temperature sensors beneath the surface. For measuring the temperature, the MFFT 20 is equipped with 20 Pt-100 temperature sensors. (MFFT 10: 10 Pt-100 sensors). The controller guarantees optimal temperature control. The temperature set points for the MFFT 20 can vary with a maximum possible gradient on the surface of 100° (MFFT 10: with a maximum gradient of 20°). Purge gas is dried by an integrated membrane dryer and flows over the heating plate. A constant flow according to the standards can be set with a built-in flow meter. The flat hinged acrylic glass cover provides thermal and atmospheric insulation while allowing constant visual inspection of the experiment.

Telefon: +49 231 91 29 80 0

Telefax: +49 231 17 98 85

E-Mail: mail@coesfeld.com





#### **Technical Data**

	MFFT 10 (50-113)	MFFT 20 (50-130)	MFFT 20 (50-131)
Variable adjustment of set point	-5°C +80°C	-30°C +250°C	-30°C +250°C
Max. gradient (depends on the used cryomate)	20°C*	100°C*	100°C*
Temperature detection	10 Pt-100 sensors in measuring plate	20 Pt-100 sensors in measuring plate	20 Pt-100 sensors in measuring plate
Resolution temperature display	0.1 K	0.1 K	0.1 K
Measuring length	500 mm	500 mm	500 mm
Measuring width	180 mm	180 mm	180 mm
Lanes	None	None	6 lanes; 300 µm depth, 20 mm width

<sup>\*</sup>ATTENTION: The maximum gradient also depends on the set temperature range and can be lower than indicated.

#### **Dimensions and Connection**

	MFFT 10 (50-113)	MFFT 20 (50-130)	MFFT 20 (50-131)
Dimensions (WxDxH)	800 x 350 x 320 mm	800 x 350 x 320 mm	800 x 350 x 320 mm
Weight	approx. 50 kg	approx. 52 kg	approx. 52 kg
Mains	230 V, 50/60 Hz	230 V (optional: 115 V)	230 V (optional: 115 V)
	(optional: 115 V)		
Power	1500 W	1500 W	1500 W
Interfaces	n.a.	n.a.	n.a.
Air	Compressed air	Compressed air	Compressed air
Cooling	Cooling connection	Cooling connection	Cooling connection
Other	n.a.	n.a.	n.a.

#### **Accessories**

incl.	Item no.	Description
-	50-037-001	Changeable hood for MFFT up to 250°C made of stainless steel 4301
-	50-034	Changeable hood for MFFT up to 80°C made of acrylic glass (720 x 280 x 250 x 5 mm)
1	9-107-085	Standard hood for MFFT up to 80°C made of acrylic glass (750 x 280 x 76 mm)
-	50-100-001	Dropping bordering made of stainless steel
-	50-047-002	Film caster 100 µm, made of plastics, for 6 parallel grooves (20 mm each)
-	50-047-008	Film caster 100 μm, made of stainless steel, for 6 parallel grooves (20mm each), with guide rolls
-	60-005-004	Cryomate, temperature range: -2040°C, for MFFT 10
-	60-005-005	Cryomate, temperature range: -45200°C, for MFFT 20

Telefon: +49 231 91 29 80 0 Telefax: +49 231 17 98 85





#### 51-... Gel Time Measurement Devices

#### **Standards**

ASTM D3451, ASTM D3532, ASTM D4217, CAN/CSA-Z245.20, DIN 16 916, DIN 55 990, EN ISO 8130-6, ISO 21809-2



#### **Application**

Instruments for determination of gel time and hardening characteristics of powder coatings and resins

#### **Features**

The exact surface temperature control and the integrated digital stop watch enable the user to produce repeatable and comparable gel times. Using a measuring spoon the specimen is filled into the polished hollows of the tempered heating plate. Simultaneously the integrated stop watch is turned on. The test piece is stirred with a stirring needle until there are no threads when pulling out the needle. When this point is reached, the watch is stopped and the gel time is read off.

#### **Technical Data**

Temperature control micro processor controller, digital temperature display

Temperature range +60 ... +250°C

Temperature accuracy  $\pm 0.1 \,^{\circ}\text{C}$  Digital stop watch  $1 \, \text{sec} \dots 24 \, \text{h}$ 

## **Device configuration**

Device	Geltest GT 16	Geltest GT 16	Geltest GT 16/20	Geltest GT 20	Geltest GT 20	Geltest GT 100
Polished hollows	1	4	2/2	1	4	plain plate
Diameter	16 mm	16 mm	2x16 mm 2x20 mm	20 mm	20 mm	100x100 mm
Item no.	51-100	51-100-001	51-103	51-104-002	51-104	51-108

Telefon: +49 231 91 29 80 0

Telefax: +49 231 17 98 85

E-Mail: mail@coesfeld.com



#### **Dimensions and Connection**

Dimensions (WxDxH)	450 x 220 x 240 mm
Weight	approx. 10 kg
Mains	230 V / 50 HZ (optional 115 V / 60 Hz)
Power	450 VA
Interfaces	n.a.
Air	n.a.
Cooling	n.a.
Others	n.a.

#### **Accessories**

incl.	Item no.	Description
-	51-114	Dust cover with door made of acryl glass
-	51-126	Handle for stirring pins Ø 1 mm
-	51-125	Handle for stirring pins Ø 2 mm
-	51-127	Stirring pins made of stainless steel Ø 1 mm (1 pack = 100 pieces)
-	51-128	Stirring pins made of stainless steel Ø 2 mm (1 pack = 100 pieces)
-	51-130	Stirring pins made of glass Ø 2 mm (1 pack = 100 pieces)
-	51-131	Measuring spoon for samples 200 mg (±10 mg)
-	51-136	Cleaning scraper brass Ø 16 mm for hollows
-	51-137	Cleaning scraper brass Ø 20 mm for hollows






## 51-145-001 Plastic granulate pouring funnel

#### **Standards**

**DIN EN ISO 6186** 



#### **Application**

Measuring system for determination of pourability plastics in form powder or granulate.

#### **Features**

- Funnel made of stainless steel, upper Ø approx. 110 mm
- Polished surface
- Funnel with earth connection
- Miscellaneous stand constructions available
- Exchangeable jets
- <u>Miscellaneous</u> jet diameters available (jets to be ordered separately)

#### **Technical Data**

Dimensions (WxDxH)

Weight

Funnel

290 x 160 x 210 mm

ca. 7.5 kg

Ø 110 mm, 40° angle

Schnittstellen n.a.
Luft n.a.
Kühlung n.a.
Andere n.a.

#### **Accessories**

incl.	Item no.	Description
-	51-146	Jet no. 1 Ø 10,0 ± 0.05 mm
-	51-147	Jet no. 2 Ø 15,0 ± 0.05 mm
-	51-148	Jet no. 3 Ø 25,0 ± 0.05 mm
-	51-149	Certificate for flotation of granulate plastics (only with jet no. 1)

Telefon: +49 231 91 29 80 0

Telefax: +49 231 17 98 85

Other jets are available on request.

E-Mail: mail@coesfeld.com






## **61-400 Apparent Density Tester**

#### **Standards**

DIN 53 466 - ISO 60 - ISO 171



#### **Application**

Measuring system for determination the apparent density of free flow powder or granulate.

#### **Features**

- Solid, warp resistant stand
- Height adjustable loading funnel
- Snap closure for loading funnel with recuparating spring
- Scraper made of stainless steel
- Calibrated measuring cup
- Drip cup for surplus material

#### **Dimensions**

Dimensions (WxDxH) 260 x 160 x 210 mm Weight approx. 3.5 kg

Funnel height: 115 mm, volume approx. 200 ml

Measuring cup 100 ±0.5 ml

9 of 15

Telefon: +49 231 91 29 80 0 Telefax: +49 231 17 98 85





## 97-230 Flotation and Apparent Density Tester

#### **Standards**

DIN EN ISO 6186 – (Apparent Density: similar to ISO 60)



#### **Application**

Measuring system for simultaneous measurement of flotation and apparent density of plastic granulate.

#### **Features**

- Time saving through simultaneous measurement
- plastic granules pouring funnel (without jet)
- apparent density measuring cup 100 ml ± 0.5 ml
- collecting cup
- moveable sealing plate
- support with holder for the pouring funnel incl. the stripper of the moulding compounds

#### **Technical Data**

Dimensions (WxDxH)	290 x 160 x 210 mm
Weight	ca. 8 kg
Funnel	Ø 110 mm, 40° angle
Interfaces	n.a.
Air	n.a.
Cooling	n.a.
Other	n.a.

#### Accessories

incl.	Item no.	Description
-	51-146	Jet no. 1 Ø 10,0 ± 0.05 mm
-	51-147	Jet no. 2 Ø 15,0 ± 0.05 mm
-	51-148	Jet no. 3 Ø 25,0 ± 0.05 mm
-	51-149	Certificate for flotation of granulate plastics (only with jet no. 1)

Telefon: +49 231 91 29 80 0

Telefax: +49 231 17 98 85

Other jets are available on request.

E-Mail: mail@coesfeld.com






## 79-200-100 Gauge Tester

#### **Standards**

DIN EN ISO 7253 - EN ISO 2409 - EN ISO 17872 - ISO 1518 - ASTM D 3359 GME 60 280 - VW PV 3952 - VDA 621



#### **Application**

All-purpose cutter for automatic scratching in surfaces with high precision and reproducibility

#### **Features**

The Gauge Tester works fully automated. The data (X-, Y-, Z-coordinates) is defined once and saved regardless of the specimen, coating and clamping device. Afterwards, repeatable and clean cuts can be carried out independently of the user.

The scope of delivery contains a large library of ready scratch guidances for a lot of standard tests according to DIN EN ISO and ASTM with all machining data. For automatic series production the parameters are set with the help of the software. CAD/CAM software is available optionally. Customized scratching patterns can be constructed this way.

Due to freely definable testing parameters there is practically no limit in terms of scratching patterns and specimen type. The load unit can be tared. With an optionally available universal weight set every load up to 50N can be chosen in 0.01N steps.

A broad variety of clamping devices is available. Additionally, customized clamping devices according to particular specifications can be delivered. With the available accessories nearly all scratching patterns and forms can be realized. This makes the Gauge Tester a flexible instrument. For example, a CNC controlled rotary plate turns the specimen automatically while a mesh-, X- or T-grid is produced. Further, a motoric load application allows automatic setting of the force needed for scrathing through the coating.

Telefon: +49 231 91 29 80 0

Telefax: +49 231 17 98 85

11 of 15

E-Mail: mail@coesfeld.com





#### **Technical Data**

Cutting stroke 200 mm x 180 mm

Height setting 90 mm

Movement speed 0.1 mm/sec ... 50 mm/sec

Working table T groove table Clamping surface (WxD) 400 x 250 mm

Propulsion 2-phase stepper motor

Controller 4-axial-microstep controller with RS232 communication interface System memory Saving of test programs for operating the tester without a PC

Telefon: +49 231 91 29 80 0

Telefax: +49 231 17 98 85

#### **Dimensions and Connection**

Dimensions (WxDxH) 535 x 600 x 690 mm

Weight ca. 70 kg
Mains 230 V, 50 Hz
Power 1500 W

Interface RS232 Air n.a.

Cooling Optional: air cooling

Other n.a.

E-Mail: mail@coesfeld.com



art.-no.: 76-170



type: Test appliance for determining the wear resistance of plastic coatings

**description:** Compact desktop appliance with acrylic glass cover for the

sample compartment. The appliance works with a motor drive and an infinitely adjustable lift path for two parallel tests. The two test places are constructed in a stainless steel tank with a drain valve, so that the tests can be carried out with the addition of liquids (cleaners, scouring agents or similar). All relevant test parameters such as speed and cycle number can be defined through the appliance's

controller.

technical data: Speed: 30 – 120 lifts/min

Sample holder with tank and drain (height approx. 30 mm)

Sample size: max. DIN A4 Sample thickness: 0.5...30 mm Lift path variable to max. 200 mm

sep. controller with specification of lift speed and lift cycles

Frame made of low-torsion ITEM profiles

max. load per test position 5 kg, the test positions must be

loaded symmetrically

Weight of clamping device and weight holder approx. 0.5 kg 7 weights per test position: 1 x 2 kg, 2 x 1 kg, 1 x 0.5 kg, 2 x

0.2 kg, 1 x 0.1 kg

Clamping device for cleaning sponges and cleaning cloths

Plexiglass safety hood

Mains connection: 230 V, 50 Hz

Telefon: +49 231 91 29 80 0

Telefax: +49 231 17 98 85

13 of 15

E-Mail: mail@coesfeld.com





## 75-091-... - Cathodic Disbonding Tester

#### **Standards**

ASTM G-8, ASTM G-42, DIN 30 670, DIN EN ISO 15711



### **Application**

The CD-Test unit tests the adhesion of plastic coatings on steel.

#### **Features**

For testing, the coating of a sample (steel pipe) is deliberately damaged so that the steel surface is exposed. Then the sample is polarized cathodically towards an anode, i.e. the steel is connected to the negative pole of an adjustable power source (potentiostat of the CD-Tester). After testing, the coating is removed and the dimension of the disbonding is rated.

Telefon: +49 231 91 29 80 0

Telefax: +49 231 17 98 85

#### **Technical Data**

Measuring stations 1 / 4 / 8 / 10 / 16 / 20 / 30 (depending on device configuration)

Nominal voltage range 5 V

Max. current ± 200 mA

Current ranges 200 mA / 20 mA / 2 mA (depending on device configuration)

E-Mail: mail@coesfeld.com



#### **Dimensions and Connection**

Dimensions (HxBxD)	4 measuring stations: 152 x 280 x 385 mm 8 measuring stations: 152 x 560 x 385 mm 16 measuring stations: 304 x 560 x 385 mm
Weight	6 / 12 / 18 kg (depending on device configuration)
Mains	230 V / 50 – 60 Hz or 110 V / 50 – 60 Hz
Power	1000 W
Interfaces	analog output
Air	n.a.
Cooling	n.a.
Others	n.a.

#### **Device configuration**

incl.	Articlenumber	Description
-	75-091-018	Cathodic Disbonding Tester 4 measuring stations, ± 5 V output; 200 mA
-	75-091-020	Cathodic Disbonding Tester 8 measuring stations, ± 5 V output; 200 mA
-	75-091-021	Cathodic Disbonding Tester 16 measuring stations, ± 5 V output; 200 mA

Other devices from 1 up to 30 measuring stations are also available.

#### **Accessories**

incl.	Articlenumber	Description
-	75-091-101	Reference electrode calomel (Hg/HgCl)
-	75-091-113	Reference electrode Ag/AgCl
-	75-091-123	Titanium anode with platinum wire Ø 0,5 mm
-	75-091-103	Titanium anode with platinum wire Ø 0,6 mm
-	75-091-114	Titanium anode with platinium wire Ø 0,8 mm
-	75-091-129	Titanium anode with platinum wire Ø 1,0 mm
-	75-091-110	Platinum coated anode Ø 8 x 120 mm
-	75-091-137	Test cup with cover made of acrylic glass Ø 74 mm with lid, 2 drill-holes
-	75-091-115	Test cup with cover made of acrylic glass Ø 74 mm with lid, 3 drill-holes
-	75-091-125	Test cup with cover made of acrylic glass Ø 74 mm with lid, 4 drill-holes
-	75-091-112	Test cup with cover made of acrylic glass Ø 80 mm
-	75-091-102	Test cup with cover made of acrylic glass Ø 100 mm
-	75-091-124	Test cup with cover made of acrylic glass Ø 100 x 145 mm
-	75-093-003	Sandbath, 50300°C, 590 x 440 mm, 4000 W, 230 V
-	75-093	Sandbath up to 350°C, 580 x 430 mm, 4000 W, 230 V
-	75-093-001	Sandbath for 4 sample plates, á 100 x 100 mm
-	KABELMCP-3.0-T	Cell cable for MCP, L 3,0 m to 100°C
-	75-091-050	Datalogger for monitoring and recording for up to 4 measuring stations
		(to be integrated into newly purchased CD-Tester)*
-	75-091-058	Datalogger for monitoring and recording for up to 8 measuring stations
		(to be integrated into newly purchased CD-Tester)*
-	75-091-057	Datalogger for monitoring and recording for up to 16 measuring stations
		(to be integrated into newly purchased CD-Tester)*
-	75-091-059	Datalogger for CD-Tester 4-place device (for retrofitting of CD-Tester)*

Normally, the number of needed reference electrodes, test cups and titanium anodes is equal the number of measuring stations. Other dataloggers (for new devices and retrofitting) are also available on request.

Telefon: +49 231 91 29 80 0

Telefax: +49 231 17 98 85

15 of 15

E-Mail: mail@coesfeld.com

<sup>\*</sup>Datalogging of two parameters, standard: voltage and temperature (selectively: current). For logging all three parameters, another logger is required (75-091-054).



# Coesfeld Materialtest the more intelligent solution ...

Force, temperature, velocity, acceleration, travel, energy - if it has to do with the accurate generation and precise measurement of physical quantities on material, it is our core expertise.

Since our establishment in 1968 as a technical service organisation we have successively expanded our activities to order related production and consequently to small batch series. Today our machines are successfully installed all over the world. This is a indication for our continuity and reliability on the one hand; on the other hand it is a proof of our aims to always find the optimal solution for our customers.

At Coesfeld, we have managed to optimize the relation of supplier network, vertical integration, core competences, costs of production and process reliability.

Goal oriented and pragmatic processes form our organisation. This approach is formulated in our ISO 9001 certified Quality Management System covering our production, service and calibration services, which are performed by our ISO/IEC 17025:2005 accredited calibration laboratory CaLab.

That is why we are confident to claim that we will provide you the more intelligent solution. We will be happy to demonstrate this to you.

Coesfeld GmbH & Co. KG Tronjestr. 8 44319 Dortmund

Tel. +49 (0) 231 91 29 80 0 Fax. +49 (0) 231 17 98 85

mail@coesfeld.com www.coesfeld.com





